



Note: Ground wire to Input Jack must be soldered to the bottom of the potentiometer where the Master Ground is soldered.