



Notes:

* 2 hookup wires are required to connect switch to tone pot.